

HENRY LONDON

Your Henry London watch is designed in England & manufactured to the very highest of standards. These instructions are provided to ensure your watch gives you excellent service, please read them carefully & retain them for future reference.

CHRONOGRAPH WITH DATE - 39mm

SETTING THE TIME

Pull the crown out to the 2nd position (B). Turn the crown clockwise to set hour and minute hands. Push the crown back into its normal position. The second hand will then resume.

SETTING THE DATE

1. Pull the crown out to the 1st position (A).
 2. Turn the crown anti-clockwise to set the date.
- Note: If the date is set between the hours of around 9:00pm and 1:00am, the date may not change the following day.
3. After the date has been set, push the crown back into its normal position.

USING THE CHRONOGRAPH

To start the chronograph press button A. The chronograph hands will start moving. To stop the chronograph press button A again. The chronograph hands stop to indicate the elapsed time. Press button B to reset the chronograph. All the chronograph hands will be reset to the '0' position. The chronograph can measure up to 30 minutes and then the chronograph stops. The chronograph can be restarted by pressing button A. During chronograph operation, button B is inoperable.

CHRONOGRAPH RESET

This procedure should be performed when the stopwatch second & minute hand does not return to the zero. Pull the crown out to the 2nd click position. Press the button "A" to set the stopwatch second hand. Press the button "B" to set the stopwatch second hand. The stopwatch minutes hand is synchronised with stop watch second hand. The stopwatch second hand can be advanced rapidly by continuously pressing button "A" or "B". Once the hand has been zeroed, reset the time and return the crown to its normal position. Follow these instructions to reset your chronograph after battery replacement.

MESH BRACELET ADJUSTMENT INSTRUCTION

If your Henry London watch has a mesh bracelet, please follow these instructions to ensure you get a perfect fit. Unlock clamp plate by using an appropriate tool. Move the entire clasp to adjust length by sliding along the bracelet. Adjust length while wearing the watch to make sure you get a good fit. Make sure the clasp locates into a molded indent on back of bracelet. Lock clamp plate in position by pressing it into place using your thumb. Do not use retaining bar to gain leverage as this will cause damage preventing the clasp to lock.

